

SUGGESTED PARTS LIST FOR INTERNAL CONTROLS FOR TOW HOOK RELEASE

RELEASE HANDLE TO SUPPORT BRACKET HARDWARE

- 1 each AN4 - 14A Bolt
- 1 each AN364 - 428A Elastic Lock Nut
- 2 each AN960 - 416L Washer (ADD additional washers as needed)

CABLE TO RELEASE HANDLE HARDWARE

- 1 each AN393 – 13 Clevis Pin
- 2 each AN960 – 10L Washers
- 1 each AN380 – 2 – 1 Cotter Pin
- 1 each AN100 – 4 Thimble
- 1 each AN115 – 21 Shackle
- 1 each 28 – 2 – G Nicopress Sleeve

SUPPORT BRACKET MOUNTING HARDWARE

- 4 each AN526 – 1032R14 Screw
- 4 each AN960 – 10L Washer
- 4 each AN365 – 1032A Nut

HARDWARE FOR MOUNTING TOW HOOK RELEASE AND INTERNAL CABLE AND TUBING.

- 5 each AN526 – 1032R14 Screws
- 5 each AN960 – 10 Washers
- 5 each AN365 – 1032A Nuts
- 5 each MS21919 – DG5 Clamps
- 1 each 28 – 2 – G Nicopress Sleeve (to connect to release mechanism)
- 1 each AN100 – 4 Thimble (to connect to release mechanism)
- 1 each AN931 – 8 – 13 Grommet

- 1 each Nylon Tubing 19ft. NNR-4-050 ¼” NAT
- 1 each 7 x 7 x 3/32 Aircraft Cable 21ft.

PARTS FROM WINGS UNLIMITED

- 1 each Release Handle (Part Number 6140)
- 1 each Support Bracket (Part Number 6150)
- 1 each Tow Hook Release (Part Number 6027, 6029, or 6030)

**NOTE –YOU WILL ALSO NEED PARTS TO ATTACH THE “TOW HOOK
RELEASE” TO YOUR AIRCRAFT. Your aircraft may require different parts than those
listed above. This list is provided for your convenience only.**